

CAM	Ai-Thinker CAM board	ESP-WROVER-KIT
D0	pin5	pin4
D1	pin18	pin5
D2	pin19	pin18
D3	pin21	pin19
D4	pin36	pin36
D5	pin39	pin39
D6	pin34	pin34
D7	pin35	pin35
XCLK	pin0	pin21
PCLK	pin22	pin22
VSYNC	pin25	pin25
HREF	pin23	pin23
SDA	pin26	pin26
SCL	pin27	pin27
RESET	pin32	pin2
<p>note:In order to reduce the usage of gpio.The reset pin of camera controls the power of camera in the Ai-Thinker CAM board .If power up the camera, GPIO32 must be pull down.</p>		